

Chapter 1

Introduction

Chapter 2

General

Section 1. Start File	3
1.1 Create File and Save	3
1.2 Import	5
1.3 Export	10
1.4 Close	12
Section 2. View Toolbar	13
2.1 View Toolbar	13
2.2 Display Mode(Geometry)	16
2.3 Display Mode(Mesh)	17
Section 3. Modeling Guide Toolbar	18
3.1 Modeling Guide Toolbar	18
3.2 Show/Hide GCS	19
3.3 Move Work Plane	20
3.4 Define Grid	21
3.5 Define Snap	21
Section 4. Select Toolbar	22
4.1 Select Toolbar	23
4.2 Select Screen	24
4.3 Selection Filter	26
4.4 Intersect	32
4.5 Select Node/Element by ID	32
Section 5. Advanced View Control Toolbar	33
5.1 Clipping Plane	33
5.2 Mirror Plane	34
5.3 Iso Value Surface	34
Section 6. Node /Element Toolbar	35
Section 7. Run Analysis Toolbar	37

Chapter 3

Geometry

Section 1. Point and Curve	39
1.1 Point	39
1.2 Line	40
1.3 Arc	41
1.4 Circle	43
1.5 Polyline	44
1.6 Rectangle	45
1.7 Ellipse	46
1.8 B-Spline	47
1.9 Profile	48
1.10 Polygon	49
1.11 Helix	50
1.12 Tunnel	51
1.13 Filet Curve & Chamfer	53
1.14 Make Wire	54
1.15 Extend Curve	56
1.16 Intersect	57
1.17 Trim Curve	58
1.18 Break Curve	59
1.19 Merge Curve	61
1.20 Offset Curve	62
1.21 Shortest Path Line	63
Section 2. Surface and Solid	64
2.1 Cylinder	64
2.2 Cone	65
2.3 Box	67
2.4 Wedge	68
2.5 Sphere	69
2.6 Torus	71
2.7 Make Face	72
2.8 Filet and Chamfer	75
2.9 Offset	76
2.10 Imprint	77
2.11 Auto Connect	79
2.12 Merge Face-Edge	80
2.13 Bedding Plane	81

Chapter 3

Geometry

Section 3. Boolean	83
3.1 Solid	83
3.2 Surface	85
Section 4. Divide	88
4.1 Solid	88
4.2 Surface	89
Section 5. Protrude	91
5.1 Extrude	91
5.2 Revolve	93
5.3 Loft	94
5.4 Sweep	96
Section 6. Transform	97
6.1 Translate	97
6.2 Rotate	98
6.3 Mirror	99
6.4 Scale	100
6.5 Sweep-Translate	100
6.6 Project	102
6.7 Attach	103
Section 7. Sub Shape	105
7.1 Super Shape	105
7.2 Remove	106
7.3 Extract	107
7.4 Explode	108
Section 8. Remove	110
8.1 Face/Edge	110
8.2 Remove Manual	112
8.3 Imprinted Object	114
Section 9. Tools	115
9.1 Options	115
9.2 Terrain Geometry Maker	118
9.3 Frame to Solid	120
9.4 Check Geometry	121
9.5 Measure	124

Chapter 4

Mesh

Section 1. Property/Coordinate/Function	125
1.1 Material	125
1.2 General Material(Behavioral Properties)	127
1.3 Material Properties	188
1.4 Property	200
1.5 Section Property	202
1.6 Complex Cross-Section Property	213
1.7 Coordinate System	214
1.8 Function	215
1.9 Hinge	248
Section 2. Control	261
2.1 Size Control	261
2.2 Default Size Control	264
2.3 Property Control	264
2.4 Match Seed	265
2.5 Layer Control	266
Section 3. Generate	267
3.1 1D	267
3.2 2D	269
3.3 3D	274
3.4 Remesh	278
Section 4. Mesh Set	279
4.1 Rename	279
4.2 Copy	280
4.3 Create	281
Section 5. Protrude	282
5.1 Extrude	282
5.2 Revolve	287
5.3 Fill	292
5.4 Sweep	295
5.5 Project	299
5.6 Offset	302

Chapter 4

Mesh

Section 6. Transform	305
6.1 Translate	305
6.2 Rotate	306
6.3 Mirror	308
6.4 Scale	309
6.5 Sweep	310
Section 7. Node	311
7.1 Create	311
7.2 Delete	313
7.3 Merge	314
7.4 Project	315
7.5 Align	316
7.6 Modify	317
7.7 Coordinate System	318
Section 8. Element	319
8.1 Create	319
8.2 Delete	327
8.3 Modify	328
8.4 Modify Topology	329
8.5 Parameters	329
8.6 Connection	336
8.7 Extract	336
8.8 Divide	337
8.9 Measure	340
8.10 Interface	340
8.11 Pile/Pile Tip	344
8.12 Free Field Element	345
8.13 Hinge	347
8.14 Infinite Element	348
8.15 Seepage Cut Off Element	349
Section 9. Tools	352
9.1 Renumber	352
9.2 Check	352
9.3 Table	357

Chapter 5

Analysis Method

Section 1. Contact	361
1.1 Define Contact	361
Section 2. Construction Stage	364
2.1 Stage Definition Wizard	365
2.2 Construction Stage Set	369
2.3 Simulate Construction Stage	374
2.4 Auto Set	375
2.5 Volume Data Export	376
Section 3. Boundary Condition	378
3.1 Define Set	380
3.2 Constraint	381
3.3 Constraint Equation	383
3.4 Change Property	384
3.5 Slip Circular Surface	386
3.6 Slip Polygonal Surface	387
3.7 Water Level	388
3.8 Nodal Head	390
3.9 Nodal Flux	393
3.10 Surface Flux	395
3.11 Review	397
3.12 Draining Condition	398
3.13 Non-consolidation	499
3.14 Create Boundary from Results	400
3.15 Boundary Table Import / Export	400
3.16 Transmitting	400
Section 4. Load	404
4.1 Self Weight	405
4.2 Force/Moment	405
4.3 Displacement	407
4.4 Pressure	408
4.5 Water Pressure	409
4.6 Beam Load	410
4.7 Temperature Load	411
4.8 Prestress	413
4.9 Initial Equilibrium Force	414
4.10 Load Set	415
4.11 Combined Load Set	416
4.12 Response Spectrum	416
4.13 Contraction	417
4.14 Load Table Import / Export	418
4.15 Response Spectrum	419
4.16 Ground Acceleration	421
4.17 Time Varying Static	423
4.18 Dynamic Nodal(Surface)	425
4.19 Load to Mass	426
4.20 Train Dynamic Load Table	427

Chapter 5

Analysis

Method

4.21 Heat Flux	428
4.22 Heat Source	429
4.23 Prescribed Temperature	430
4.24 Convection	430
Section 5. Wizard and Tools	432
5.1 Tunnel Modeling	432
5.2 Anchor Modeling	438
5.3 Soil Test	439
5.4 Seismic Data Generator	442
5.5 Dynamic Load Data Generator	444
5.6 Free Field Analysis	447
5.7 Artificial Earthquake Generator	457

Chapter 6

Analysis

Section 1. Analysis Case	461
1.1 General	461
1.2 Solution Type	463
1.3 Analysis Control(Optional)	477
1.4 Time Step	485
1.5 Output Control	496
1.6 Analysis Setting	497
1.7 Parametric Analysis	498
Section 2. Analysis	499
2.1 Perform/Batch Analysis	499
Section 3. History	500
3.1 History Output Probes	500

Chapter 7

Result and Tools

Section 1. Result	503
1.1 Combination	503
1.2 Calculation	504
Section 2. General	505
2.1 Contour	505
2.2 Vector	507
2.3 Diagram	511
2.4 Smooth	513
2.5 Fill	514
2.6 Edge Type	515
2.7 Deform	516
2.8 No Results	519
Section 3. Advanced Function	520
3.1 Probe	520
3.2 Multi Step Iso Surface	521
3.3 Extract	522
3.4 Local Direction Force Sum	523
3.5 Cutting Diagram	524
3.6 Others – Elementary Contour Plot	525
3.7 Others – Summation of Reaction	525
3.8 Others – Convert to Decibel	526
3.9 Others – 3D-2D Wizard	527
3.10 Others – Multi Step Graph	529
Section 4. Special Post	530
4.1 Seepage	530
4.2 Slope Stability(SAM) Result	532
4.3 History	534
Section 5. Etc.	536
5.1 Image File	536
5.2 Initialize	537
Section 6. Geometry	538
6.1 Change Color	538
6.2 Color Type	539
6.3 Random Color	539
Section 7. Node/Element	540
7.1 Query	540

Chapter 7

Result and Tools

Section 8. Export to 3D PDF	541
8.1 Export to 3D PDF	541
Section 9. Flight Simulation	542
9.1 Flight Simulation	542